

## C&DH

CAUTION  
ALARM


Attention Symbol  
will appear on card

User Notification

Attention Symbol or  
call from crew or  
another console  
with funny data


Nominal Config:  
Mal:Nom:Text

## NODE 1 MDM I/O CARD FAILURE PROCEDURE



①

Before resetting the card, decide if card is supporting more important tasks on any good channel and if want to wait to reset the card. This is done via the Node Channelization Chart.



②  
Check with MCC to  
decide if want to  
power cycle the  
MDM to try and  
regain the I/O card.